

ADMONTER IN BATHROOMS

FLOORs

All Admonter FLOORs, except for those marked in the data sheet, are suitable for installation in bathrooms subject to the following conditions:

- Full-surface glue-down installation with Admonter Elastic adhesive
- Natural oiled finish
- Initial oiling with Admonter maintenance oil (after installation) and re-oiling of the floor when necessary. It is important that a continuous oil layer covers the floor, especially in the area of the bevels.
- Use waterproof elastic silicon or alike to close gaps between the floor and the walls.
- Avoid standing water. If water drops on the floor, immediately get rid off the water in order to avoid water stains.

FLOORs and ELEMENTs

- Before use test bath salts and shower gels on unremarkable spots of the floor to avoid possible colour stains.
- Please make sure that the average room climate complies with the installation and maintenance instructions. Short-term excess or undercutting temperatures can be disregarded.
- Assignment of the stress classes according to the Austrian standard norm ÖNorm B 3407:
 - Up to and including W2 – permissible
 - W3 – permissible, except for shower and splash water area
 - W4 and higher – not permissible
- Any necessary structural waterproofing must be planned and installed by the designer.
- Please follow the instructions of the current installation and maintenance guide.
- For installation on walls or ceilings: permanent, sufficient rear ventilation is needed
- Condensation on cold building components must be countered by suitable building physics measures.

March 2021

Admonter
Holzindustrie AG

8911 Admont / Austria, Sägestraße 539

phone: +43(0)3613/3350-0, fax: +43(0)3613/3350-119, e-mail: info@admonter.at

FN237499p (LG Leoben) Gerichtsstand Liezen, UID-Nr.: ATU57198366

Bankverbindung: Raiffeisenbank Admont, IBAN: AT88 3800 1000 0002 7276, BIC: RZSTAT2G001

